



Installation Checklist – 3 Sided Guards

Posts: Are / Is the:

- 🌱 Foot Adjustable Anchor inserted on the tall posts closest to the street?
- 🌱 Post Braces added to the tall posts closest to the street?
- 🌱 Posts firmly inside the pit and not on the sidewalk?
- 🌱 Posts and Floating Feet firmly on the soil? Build up and compact the soil if possible or use adjustable feet if necessary.
- 🌱 Posts Anchored in properly with Stakes?
- 🌱 Rod Topper on and are the Rods pounded half way down the Post?

Rails: Are / Is the:

- 🌱 Screws in the rails hand tightened and not stripped?
- 🌱 Screw and weld nut or Corner Brace covering the Panel Groove to prevent panel theft?
- 🌱 Rail Connectors added (All rails 5.5 feet and longer)?

Other: Are / Is the:

- 🌱 Corner Braces added?
- 🌱 Right amount of panels installed (2 min for 5 to 8' and 3 for 8.5 to 10')?
- 🌱 Panels evenly spaced?
- 🌱 Panel Cushioning in placed. Remember small 4 inch pieces on the bottom and top of the panels.
- 🌱 Screws not threading properly? If so use the threading screw in BAG A to retap.
- 🌱 Guard at least 18" away from the street?
- 🌱 Guard far enough away from driveways other potential threats?
- 🌱 Swoops (if purchased) aligned properly and straight to the eye?